

How to switch GS R1521 Trigger Mode

Standard Mode: A trigger press activates decode processing. Decode processing continues until the barcode decodes or you release the trigger.

Presentation Mode: The decoder activates decode processing when it detects a barcode in its field of view. After a period of non-use, the LEDs turn off until the decoder senses motion.

Please scan the barcode below to switch the Trigger Mode



Standard Mode



Presentation Mode