

How to upgrade firmware in OTA

Version 1.0

Feb - 22

Table of Contents

Copyright	3
Service Information	3
Revision History	3
Overview	4
Operation.....	4

Copyright

GENERALSCAN reserves the right to make changes to any product to improve reliability, function, or design.

GENERALSCAN does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

Service Information

If there is a question with the barcode scanner, you can visit website for the live chat at: www.generalscan.com

Revision History

Version	Date	Description
1.0	Feb-22	Initial Release

Overview

This function is used for on-line detection of the latest firmware and on-line firmware upgrade of products.

Operation


Step1: Scan the barcode to put the scanner into upgrade mode, and you will find that the green light and blue light are both flashing.




Enter DFU Mode




Step2: Install the APP "DFU Tools" ,and start the APP, Click the Bluetooth icon, enter Bluetooth pair



Step3: Click the "GO TURN ON" button to turn on the phone's Bluetooth, then click the "GO SELECT" to choose the scanner that need to upgrade.




Step4: After input the PN Number “1234”, then click the “ok”, the Bluetooth connection will build.



Step 5: Click the “CHECK UPDATE” button to check if there is a new firmware can be used to update. You can see the current version information of the firmware after the Bluetooth connection.



Step6: If you need to update the firmware, please click the “UPDATE” button. Then the update process will start. Do not interrupt the update process.



Step7: Click the “OK”, exit the update. After the update process, the scanner will shut down.

