

## Cradle and Bluetooth Adaptor



### [Cradle for Flexgrip-wireless version - GS GDH201](#)

It is an all-in-one charging and data-transfer cradle specially designed for Generalscan handheld scanner-Flexgrip-wireless version. It is applied to all the Generalscan scanners of R1120, R152X, R352X, and R552X series.

Includes: RJ45/USB Cable [886783046001](#), RJ45/RS232 Cable [886783049001](#)

Wear Guide Video Link - [https://youtu.be/YLIGevdu\\_c](https://youtu.be/YLIGevdu_c)



### [1v1 Bluetooth Adaptor - GS GDA201](#)

It connects Generalscan scanners of R1120, R152X, R352X, and R552X series to terminal devices that without Bluetooth capability or with an unstable Bluetooth connection via Bluetooth.

Includes: RJ45/USB Cable [886783046001](#), RJ45/RS232 Cable [886783049001](#)

User Guide Video Link - <https://youtu.be/DfVgridJytY>



### [5-in-1 Bluetooth Adaptor - GS GDA202](#)

It connects Generalscan scanners of R1120, R152X, R352X, and R552X series to terminal devices without Bluetooth capability or with an unstable Bluetooth connection via Bluetooth. Five scanners can be connected at a time.

Includes: RJ45/USB Cable [886783046001](#), RJ45/RS232 Cable [886783049001](#)

User Guide Video Link - <https://youtu.be/DfVgridJytY>