

How to connect with Bluetooth BLE (Android)

Version 1.0

May - 22

Table of Contents

Copyright.....	3
Service Information.....	3
Revision History.....	3
Overview.....	4
Download.....	4
Operation.....	5

Copyright

GENERALSCAN reserves the right to make changes to any product to improve reliability, function, or design.

GENERALSCAN does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

Service Information

If there is a question with the barcode scanner, you can visit website for the live chat at: www.generalscan.com

Revision History

Version	Date	Description
1.0	May-22	Initial Release


Overview

This file is used to introduce how to use “Bluetooth BLE Mode” of the scanner to connect with Android device.

Video: <https://youtu.be/0mWJSX-DFLk>


Download

The APP that is mentioned in the file, can search “serial Bluetooth terminal” in Google play, choose the program that in the red box to download and install.



Operation

Step1: Scan “Default Factory Setting” , after scanning, the blue indicator light will be in quickly flashing status.




Default Factory Setting

Step2: Scan the barcode of “Bluetooth BLE Mode” , observe the blue indicator light of the scanner is two quickly and one slowly flashing status.




Bluetooth BLE Mode


Step3: Open the "Settings" of mobile phone.




Step4: Choose "Bluetooth"



Step5: Choose scanner connection.





Step6: Scanner pairs successfully.




Step7: Open Serial Bluetooth Terminal (This APP was used to show, customer can use own serial APP).



Step8: Click the left upper corner of the software interface, and then choose "Device".



Step9: Choose Bluetooth LE, and then choose the scanner's name that needs to connect, can see the connect successfully reminder, blue indicator light goes out.



Step10: Scan the barcode, can see information outputting.

